



NOTE: Pins 23 & 10 and/or 24 & 11 may be used to interrupt ignition and/or injector power.

These pins are redundant if using pin 12 to cut the engine using the management.

If using pin 12, the management MUST support "cut while input active"

NOTE: Compressor current is 16 Amps (intermittent)  
Use 16AWG (2mm sq) wire minimum

|                             |            |                      |                           |
|-----------------------------|------------|----------------------|---------------------------|
| Designed by<br>Neil Wallace | Checked by | Approved by - date   | Date<br>27/01/2008        |
| Geartronics Ltd.            |            | <b>GCU schematic</b> |                           |
|                             |            | schematic            | Edition<br>Sheet<br>1 / 1 |